Autonics

• Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.

• Δ symbol indicates caution due to special circumstances in which hazards may occur.

Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.
- Failure to follow this instruction may result in explosion or fire. **03. Install on a device panel to use.**
- Failure to follow this instruction may result in fire or electric shock.
 04. Do not connect, repair, or inspect the unit while connected to a power source.
- Failure to follow this instruction may result in fire or electric shock. **05. Check 'Connections' before wiring.**
- Failure to follow this instruction may result in fire. **06. Do not disassemble or modify the unit.** Failure to follow this instruction may result in fire or electric shock.

Caution Failure to follow instructions may result in injury or product damage.


- 01. Use the unit within the rated specifications.
- Failure to follow this instruction may result in fire or product damage. **02. Use a dry cloth to clean the unit, and do not use water or organic solvent.**
- Failure to follow this instruction may result in fire or electric shock.
 03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.

Failure to follow this instruction may result in fire or product damage.

Cautions during Use

Safety Considerations

- Follow instructions in 'Cautions during Use'.
- Otherwise, it may cause unexpected accidents. • Power supply should be insulated and limited voltage/current or Class2, SELV power supply device.
- When supplying or turning off the power, use a switch or etc. to avoid chattering.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- In order to avoid leakage current flowing, connect resistance and condenser like below. Otherwise, it may cause malfunction.



• After turning off the power, change the time range, etc.

Keep away from high voltage lines or power lines to prevent inductive noise. In case
installing power line and input signal line closely, use line filter or varistor at power line
and shielded wire at input signal line.

Do not use near the equipment which generates strong magnetic force or high frequency noise.

- This unit may be used in the following environments.
 Indoors (in the environment condition rated in 'Specifications')
- Indoors (in the environment condition rated in "Specifications") - Altitude max. 2,000 m
- Pollution degree 2
- Installation category II

W 21.5 \times H 28 mm Analog Timers



ATM Series PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Features

- Miniature Size (W 21. 5 \times H 28 \times L 59.3 mm)
- 4c (4PDT) contact (250 VAC∼, 3 A)
- High precise time control
- Easy time setting using dial
- Various time ranges
- : 0.1 sec to 3 hour (11 time ranges, different by models)
- Power supply ATM4-2: 24 VDC==
 ATM4-5: 220 VAC~ 50 / 60 Hz ATM4-6: 110 VAC~ 50 / 60 Hz

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

ATM4 - **0 9 9**

Power supply
 2: 24 VDC ==
 5: 220 VAC ~ 50 / 60 Hz

6: 110 VAC $\sim 50\,/\,60$ Hz

Time unit S: SEC

M: MIN H: HOUR

O Time range

Number: max. time


Product Components

• Product


Instruction manual

Dimensions


- Unit: mm, For the detailed drawings, follow the Autonics website.
- Mount the My socket (sold separately).



Pin arrangement



Unit Descriptions




Time Range

Model	Unit	Range
ATM4-D1S		0.1 to 1
ATM4- 5S		0.5 to 5
ATM4- 10S	SEC	1 to 10
ATM4- 30S		3 to 30
ATM4- 60S		6 to 60
ATM4- 3M		0.3 to 3
ATM4-D5M		0.5 to 5
ATM4-D10M	MIN	1 to 10
ATM4- 30M		3 to 30
ATM4- 60M		6 to 60
ATM4-D3H	HOUR	0.3 to 3

Operation Timing Chart

• t: setting time, Rt : return time





Connections

 $\underline{\mathbb{A}}$ Caution : Refer to the 'specifications' for checking the power supply and control output.

IEC marking

• This type of connection is marked on the product.





SOURCE

Specifications					
Model	ATM4-2	ATM4-5	ATM4-6		
Function	Power ON Delay				
Return time	\leq 100 ms				
Time operation	Power ON Start				
Control output	Relay				
Contact type	4PDT (4c)				
Contact capacity	250 VAC~ 3 A, 24 VDC== 3 A resistive load				
Error	$\begin{aligned} & \text{Repeat:} \leq \pm \ 0.5\% \pm 10 \ \text{ms} \\ & \text{SET:} \leq \pm \ 10\% \pm 50 \ \text{ms} \\ & \text{Voltage:} \leq \pm \ 0.5\% \pm 10 \ \text{ms} \\ & \text{Temp:} \leq \pm \ 2\% \pm 10 \ \text{ms} \end{aligned}$				
Approval	C € ERE				
Unit weight (packaged)	\approx 42 g (\approx 48 g)				

B	241/06	2221/02 50/2011	110,000 50 (00,0		
Power supply	24 VDC==	220 VAC \sim 50 / 60 Hz	110 VAC \sim 50 / 60 Hz		
Allowable voltage range	21.6-26.4 VDC==	200-230 VAC~ 50/60 Hz	100 - 120 VAC $\sim 50/60\text{Hz}$		
Power consumption	\approx 1.2 W	$\approx 3 \text{ VA}$	$\approx 3 \text{ VA}$		
Insulation resistive	\geq 100 M Ω (500 VDC== megger)				
Dielectric strength	3,000 VAC \sim at 50 / 60 Hz for 1 min				
Noise immunity	$\pm2\text{kV}$ square-wave noise by noise simulator (pulse width $1\mu\text{s})$				
Vibration	0.75 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 1 hour				
Vibration (malfunction)	0.5 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 10 min				
Shock	300 m/s ² (≈ 30 G) in each X, Y, Z direction for 3 times				
Shock (malfunction)	$100 \text{ m/s}^2 (\approx 10 \text{ G}) \text{ In each X, Y, Z direction for 3 times}$				
Relay life cycle	$\begin{array}{l} \mbox{Mechanical:} \geq 10,000,000 \mbox{ operations} \\ \mbox{Electrical:} \geq 200,000 \mbox{ operations} \end{array}$				
Ambient temperature	-10 to 50 °C, storage: -25 to 65 °C (no freezing or condensation)				
Ambient humidity	35 to 85%RH, storage: 35 to 85%RH (no freezing or condensation)				