DRW161278AD\_MODI Autonics

# 8-pin Plug Digital Timers With Thumb wheel Switch



### **FSE Series**

## PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

#### **Features**

- Wide range of the time selection (0.01 sec to 9999.9 hour)
- Selectable voltage input (PNP) method or no-voltage input (NPN) method
- $\bullet$  Dot for Decimal Point / Hour. Min. Sec. by RESET key
- Wide range of power supply : 100 240 VAC  $\sim 50$  / 60 Hz, 24 VAC  $\sim 50$  / 60 Hz, 24 48 VDC  $\Longrightarrow$  universal
- Memory protection for 10 years (using non-volatile semiconductor)
- Built-in Microprocessor

#### **Safety Considerations**

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

**⚠ Warning** Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.(e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)

  Failure to follow this instruction may result in personal injury, economic loss or fire.
- Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.

Failure to follow this instruction may result in explosion or fire.

- 03. Install on a device panel to use.
  - Failure to follow this instruction may result in fire or electric shock.
- 04. Do not connect, repair, or inspect the unit while connected to a power source.

Failure to follow this instruction may result in fire or electric shock.

- 05. Check 'Connections' before wiring.
  - Failure to follow this instruction may result in fire.
- 06. Do not disassemble or modify the unit.

Failure to follow this instruction may result in fire or electric shock.

▲ Caution Failure to follow instructions may result in injury or product damage.

- 01. When connecting the power /sensor input and relay output, use AWG 20 (0.50 mm²) cable or over, and tighten the terminal screw with a tightening torque of 0.74 to 0.90 N m.
  - Failure to follow this instruction may result in malfunction due to contact failure.
- 02. Use the unit within the rated specifications.
  - Failure to follow this instruction may result in fire or product damage.
- **03.** Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in fire or electric shock.
- 04. Keep the product away from metal chip, dust, and wire residue which flow into the unit.

Failure to follow this instruction may result in fire or product damage.

#### **Cautions during Use**

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- Power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Use the product, 0.1 sec after supplying power.
- When supplying or turning off the power, use a switch or etc. to avoid chattering.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power..
- Keep away from high voltage lines or power lines to prevent inductive noise. In case installing power line and input signal line closely, use line filter or varistor at power line and shielded wire at input signal line.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
- After turning off the power, change the time range, etc.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2,000 m
- Pollution degree 2
- Installation category II

#### **Ordering Information**

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

FS 0 E - 2 3

• Display digits

4: 4-digit 5: 5-digit **3** Power supply

2: 24 VAC ~ 50 / 60 Hz, 24 - 48 VDC == 4: 100 - 240 VAC ~ 50 / 60 Hz

Output

1P: 1-stage setting (4-digit) I: Indicator (5-digit)

#### **Product Components**

• Product (+ bracket)

• Instruction manual


#### **Sold Separately**

• 8-pin socket: PG-08, PS-08(N)

#### **Dimensions**

 $\bullet$  Unit: mm, For the detailed drawings, follow the Autonics website.





#### ■ Bracket















#### Connections

#### **△** Caution


: Refer to the 'specifications' for checking the power supply and control output.

#### **■** FS4E-1P4





#### FS5E-I4



#### Error

- When error occurs, the output turns OFF.
- Indicator model does not have error display function.

Display	Description	Troubleshooting
ErrO	Setting value = 0	Change the setting value anything but 0.

#### **Specifications**

			1
Model	FS4E-1P2	FS5E-1P4	FS5E-I4
Display digits	4-digit		5-digit
Character size	W 3.8 × H 7.6 mm		W4×H8mm
Return time	≤ 500 ms		
Time operation	Power ON Start		
Min. signal width	RESET, INHIBIT: ≈ 20	ms	
Input logic	Voltage input (PNP) - input impedance: $\leq 10.8  \mathrm{k}\Omega$ , [H]: $5$ - $30  \mathrm{VDC}$ ==, [L]: $0$ - $2  \mathrm{VDC}$ == No-voltage input (NPN) - short-circuit impedance: $\leq 470  \Omega$ , - short-circuit residual voltage: $\leq 1  \mathrm{VDC}$ = - open-circuit impedance: $\geq 100  \mathrm{k}\Omega$		
One-shot output time	0.05 to 5 sec		
Control output	Relay		-
Contact type	Time limit SPDT (1c)		-
Contact capacity	250 VAC~ 3 A, 30 VDC	== 3 A resistive load	-
Error	Repeat / SET / Voltage	e/Temp.: ≤ ± 0.01% ±	± 0.05 sec
Unit weight (packaged)	≈ 90 g (≈ 130 g)		≈ 80 g (≈ 120 g)
Approval	C€ c <b>PU</b> us ERI		

Voltage type	AC voltage type	AC / DC voltage type	
Power supply	100 - 240 VAC~ ± 10% 50 / 60 Hz	24 VAC~ ± 10% 50 / 60 Hz, 24 - 48 VDC== ± 10%	
Power consumption (FS5E-1P4)	≤ 4.6 VA	-	
Power consumption (FS5E-I4)	≤ 3.8 VA	-	
Power consumption (FS4E-1P2)	-	AC: ≤ 3.5 VA DC: ≤ 2.3 W	
Memory retention	pprox 10 years (non-volatile semicon	ductor memory type)	
Insulation resistance	$\geq$ 100 M $\Omega$ (500 VDC== megger)		
Dielectric strength	$2,000  \text{VAC} \sim 50  /  60  \text{Hz}$ for $1  \text{min}$ (between all terminals and case)		
Noise immunity	± 2 kV square-wave noise by noise simulator (pulse width 1 μs)	± 500 V square-wave noise by noise simulator (pulse width 1 μs)	
Vibration	0.75 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) is each X, Y, Z direction for 1 hour		
Vibration (malfunction)	0.5 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 10 min		
Shock	300 m/s² (≈ 30 G) in each X, Y, Z direction for 3 times		
Shock (malfunction)	100 m/s² (≈ 10 G) in each X, Y, Z direction for 3 times		
Relay life cycle	Mechanical: $\geq$ 5,000,000 operations Electrical: $\geq$ 100,000 operations (250 VAC $\sim$ 3 A resistive load)		
Ambient temperature	-10 to 55 °C, storage: -25 to 65 °C (no freezing or condensation)		
Ambient humidity	35 to 85%RH, storage: 35 to 85%RH (no freezing or condensation)		
Protection rating	IP20 (front part, IEC standard)		

#### **Mode Setting**



[RESET] 3 sec



[RESET] 3 sec



#### Dot for Hour / Min / Second

- If there is no RESET key or DIP switch input for 60 sec, it returns to RUN mode.
- $\bullet \; [\mathsf{RESET}] \; \mathsf{key} \text{: Setting mode} \leftrightarrow \mathsf{RUN} \; \mathsf{mode}$

Move the digit when changing the setting value.


Parameter	Display	Setting range	Setting example
T1-1 Setting mode	dР	=	=
T1-2 Setting of dot for Hour / Min / Sec	ELr	CLR: not divided with dot	5959: 59 m 59 s
Hour/Min/Sec		SET: divided with dot	0.59.59: 59 m 59 s

#### **Output Operation Mode**

For the detailed timing chart for operation output mode, refer to the manual.

#### **Detach DIP Switch Cover**

Front



• Push and pull the groove of DIP switch cover with a flat head (-) driver to the front, removing the cover from the case.

 $\underline{\Lambda}$  Caution: Turn OFF the power before removing the cover.

 $\underline{\wedge}$  Caution: When using the tools, be careful not to be wounded.

#### **DIP Switch Setting**



- Detach the cover of DIP switch and proceed the settings. Refer to the 'Detach DIP Switch Cover.'
- How to change the settings:
   power OFF → change settings → power ON
   → press [RESET] key or input the RESET
   signal (≥ 20 ms) to the external terminal.

#### ■ DIP SW1

SW1 Function		Defaults
1	INHIBIT, RESET input logic	ON
2, 3, 4 Time range		OFF
5	Count up / count down	OFF
6	Memory retention	OFF

#### • Input logic

SW1-1	Input logic
ON	NPN (No-voltage input)
OFF	PNP (voltage input)

#### • Time range

SW1-2,3,4		Time range		
4	3	2	4-digit	5-digit
OFF	OFF	OFF	99.99 s	9999.9 s
OFF	OFF	ON	999.9 s	99999 s
OFF	ON	OFF	9999 s	9 m 59.99 s
OFF	ON	ON	99 m 59 s	99 m 59.9 s
ON	OFF	OFF	999.9 m	9999.9 m
ON	OFF	ON	99 h 59 m	9 h 59 m 59 s
ON	ON	OFF	999.9 h	999 h 59 m
ON	ON	ON	9999 h	9999.9 h

#### • Count up / count down

SW1-5	Count up / count down
ON	Count down
OFF	Count up

#### Memory retention

SW1-6	Memory retention	
ON	×	
OFF	0	

#### ■ DIP SW2

SW2	Function	Defaults
1.2.3	Output operation mode 01)	OFF

01) Except the indicator model.

#### Output operation mode


p p			
SW2			Outnut eneration made
3	2	1	Output operation mode
OFF	OFF	OFF	F
OFF	OFF	ON	N
OFF	ON	OFF	С
OFF	ON	ON	R
ON	OFF	OFF	K
ON	OFF	ON	Р
ON	ON	OFF	Q
ON	ON	ON	S

#### **Input Connections**

Input: INHIBIT, RESET

#### ■ No-voltage (NPN) input

#### Solid-state input




#### Contact input


# Timer +12 V ≤ 5.4 kΩ Internal circuit of input part

#### ■ Voltage (PNP) input

#### Solid-state input




#### Contact input




#### **Output operation mode**

 Output type
 One-shot output Retained (hold) output

• Set One-shot output time via [TIME] volume switch on the front side. Setting range: 0.05 to 5 sec



#### ■ Time operation (for indicator model)



• (-) display is only for F, K, Q, S output operation mode and it cannot be set.